


MARNING: CHOKING HAZARD--Small parts. Not for children under 3 years.

AGES 3+

spiegraph (

- Lift the frame and place a sheet of paper inside the corner marks as shown to the right.
- 2. Close the frame.
 Place the large
 gear ring inside
 the teeth of the
 frame to lock it
 into place.
- 3. Choose a gear and place it inside the gear ring so the teeth are engaged. We recommend gear A to start.





4. Insert a marker into one of the holes in the gear. Holding the marker upright as shown, move the gear along the teeth on the inside of the gear ring.

Continue drawing until the marker meets back up with the point where the design began.



Tip: For best results hold the marker straight up and down, move it slowly and don't put too much pressure on the gear.


Using the Frame


You can also move the gears around the teeth inside the frame to create rectangle designs. They make great picture frames!





Creating designs with the gears


Each gear and hole will create a unique design. This chart will show you what gear and hole to use to draw each design.













- The holes in the gears work with the markers included in this kit, but will also work with other markers and crayons.
- Practice! Practice!
 Practice! Discover the possibilities as you draw more Spirograph' designs.
- The desk is designed to work with half of an 8.5x11 inch standard sheet of paper.

 Your Spirograph® carry-along desk is a great place to neatly store all of your supplies!





HASBRO and its logo, SPIROGRAPH® and its logo are trademarks of Hasbro and are used with permission. ©2016 HASBRO. All Rights Reserved.

Manufactured and Distributed by Kahootz, LLC.

2016 Kahootz, LLC • 772 Airport Boulevard, Suite 1 • Ann Arbor, MI 48108

www.KahootzToys.com

STAIN ADVISEMENT: Ink may stain some surfaces. Keep away from painted walls, wallpaper, wood, vinyl, carpeting and other materials that ronnot be laundered. FOR BEST RESULTS: Markers can be washed from skin and most washable clothing. Wash promptly in hat water. Do not use prewash or chlorine bleach. Repeat laundering may be required.



